



FIG. 148.—Application of the provisional appliance for below-the-knee amputation. The provisional appliance is then applied, the joint centered carefully in relation to the knee, and the frame incorporated in the plaster socket by additional turns of plaster bandage.