



FIG. 150.—Application of the provisional appliance for below-the-leg amputation. The upper margin of the socket is carefully lined with pencil, passing front just below the patella and being hollowed out behind to allow flexion of the knee