MOBILE X-RAY OUTFIT

PORTABLE X-RAY OUTFIT MOUNTED IN AMBULANCE BODY	Instrument box, etc.—Continued.
D	Rheostat as specified.
Booster for portable apparatus.	Wiring diagram.
Gasoline-electric set (Delco)	Operating switch.
Filament control, inductive type	Tool set complete
Rheostat for solenoid control of engine speed	Cables, 50 feet
Transformer:	Chibics, ou ice
For portable apparatus, closed core type, oil	UNITED STATES ARMY BEDSIDE X-RAY UNIT
insulation, with oil-tight top	Cabinet and tune holder
Coolidge filament lighting, oil insulated, with	High-tension transformer
an oil-tight cover1	
Table, X-ray, for portable, apparatus complete,	8-foot, to connect with electric service.
with rail frame 1	10-foot, with foot switch
Table tops of continental Bakelite	
Fluoroscope for portable apparatus, 10 by 10 inches,	Lead-glass shield
with carriers 1	
Tube, special Coolidge air-cooled type, with	Single, to connect with positive end of Cool-
radiation type of anode3	
Voltmeter, alternating current, scale C-175	1485 1485 1485 1485 1485 1485 1485 1485
Instrument box, in which are permanently the	with negative end of Coolidge tube
following:	
X-ray transformer 1	Wiring diagram
	, and do not core; and the core
Coolidge filament transformer,	Rotary converter (will start on 220 volts)
Filament control.	Fluoroscope, 11 by 14, special folding, as furnished
Milliameter, 0 to 15 milliamperes.	by W. & B
Voltmeter as specified.	10-ampere screw fuse plugs